

**MATERIALS FOR SENSORS
AND ELECTRONICS**

LAB REPORT:

FERROELECTRICITY - PERMITTIVITY

By:

Chakra Shree Harsha Aravilli Venkata,

Matrikel Nr: **651503**

Under the guidance of:

PROF. David Smykalla

Table of Contents

| | |
|---|----|
| ABSTRACT | 3 |
| THEORY | 4 |
| PROCEDURE | 5 |
| OBSERVATIONS | 6 |
| Readings for Increasing Temperature | 6 |
| Readings for Decreasing Temperature | 8 |
| GRAPHS & DISCUSSIONS | 9 |
| PERMITTIVITY | 9 |
| INVERSE OF RELATIVE PERMITTIVITY | 11 |
| CONCLUSION | 12 |

List of Graphs


| | |
|---|----|
| Graph 1: Theoretical Permittivity vs Temperature..... | 4 |
| Graph 2: Theoretical Inverse Relative Permittivity vs Temperature | 4 |
| Graph 3: Permittivity vs Temperature under Heating process | 10 |
| Graph 4: Permittivity vs Temperature under Cooling process..... | 10 |
| Graph 5: Inverse relative permittivity vs temperature under Heating process | 11 |
| Graph 6: Inverse relative permittivity vs temperature under cooling process | 11 |

ABSTRACT


The dielectric constant or permittivity, of a material is an important feature in electricity and magnetism. It shows how well a material can store electrical energy. To find the dielectric constant of a solid, we measure the capacitance of a capacitor that has the material inside it. In this experiment, we will find the dielectric constant (ϵ) of a TGS crystal. We'll see how it changes with temperature, starting from room temperature up to 75°C. We will do this at a frequency of about 2 kHz. The experiment consists of two parts. Increasing Temperature, we will slowly increase the temperature and measure the dielectric constant of the TGS crystal at different points. This will show us how the material behaves as it gets hotter. Decreasing Temperature, after reaching 75°C, we will let the crystal cool down and again measure the dielectric constant at different temperatures. This will help us see if there are any differences between heating and cooling. By doing this, we will learn how the TGS crystal's dielectric properties change with temperature.

THEORY

Landau theory is a theory that was introduced by Lev Landau to formulate a general theory of continuous phase transitions (Second order), it can be also used as a quantitative model for discontinuous transitions (First order). Landau's theory also states that the curie constant is different for heating and cooling phases.



Graph 1: Theoretical Permittivity vs Temperature



Graph 2: Theoretical Inverse Relative Permittivity vs Temperature

The dielectric constant (also called permittivity) ϵ of a dielectric material is measured mostly by determining the capacitance of the parallel plate capacitor containing the material. The capacity of a parallel plate capacitor is given by

$$C = \epsilon \cdot \frac{A}{d} \quad \text{with} \quad \epsilon = \epsilon_0 \cdot \epsilon_r$$

where,

C – capacity of the parallel plate capacitor

A – area of the plates facing each other

d – distance of the two plates

ϵ – dielectric constant, also called permittivity

ϵ_0 – dielectric constant or permittivity of the vacuum

ϵ_r – Relative dielectric constant or relative permittivity of a special material

For calculating the **Inverse Relative Permittivity**, we have

$$\frac{1}{\epsilon_r} = \frac{\epsilon_0}{\epsilon}$$

where,

ϵ_r – Relative permittivity

ϵ_0 – Permittivity of Free space (0.00885 pF/mm)

ϵ – Permittivity of TGS Crystal.

Here, we considered **Sample A** which have Thickness (d) as 1.01 mm and Area (A) 31.50 mm². So, the permittivity of this crystal can be given as shown below

$$\varepsilon = \frac{C * 1.01 \text{ mm}}{31.50 \text{ mm}^2}$$

here,

C – Capacitance is converted from Millivolts from the experimental setup 1mV=1pF

PROCEDURE

- Connect the two BNC connectors of the small aluminium sample box via BNC cables with the BNC connectors of the capacity measuring box. The two contacts of the sample relate to the middle wire. The outer shell of the BNC connectors is only used for shielding.
- Connect a digital handheld multimeter with the output connectors of the capacity measuring box (black and red connectors). Use at first the V-AC range of the multimeter.
- Switch the multimeter on. Now you should see on the multimeter a voltage that corresponds to the capacity of the sample. 1 mV corresponds to 1pF.
- Connect the heater inside of the aluminium sample box (black and red connector) with the current supply. In the beginning, the current supply is switched off.
- Connect the DIN female connector of the aluminium sample box with the DIN female connector of the temperature measuring box. Use the brown cable with the two DIN male connectors.
- Connect a digital multimeter with the output of the temperature measuring box (black and red connectors). Use the 20 V DC range of the multimeter.
- Switch the multimeter on. Now you should see on the multimeter a voltage that corresponds to the temperature of the sample. 0.1 V corresponds to 1 °C.
- Now begin with the measurement of the temperature dependence of the sample capacity. Switch the heating current on and measure the capacity in intervals of about 1 °C. The heating voltage should be not too high. Otherwise, you get temperature measuring errors. Between room temperature and 47 °C, you should use a temperature increasing velocity of about 1 °C/minute. As a recommended value use a heating voltage of about 5 V. In the region between 47 °C and about 51 °C (until you notice that the Curie temperature is passed) the heating velocity should be very slow. Try to use about **0.2 °C/minute** and measure in intervals of about 0.2 °C. If you have passed the Curie temperature you can increase the heating velocity again to about 1 °C/minute. Be careful! Do not exceed a sample temperature of 75 °C.

- After reaching 65 °C reduce the heating current and measure the sample capacity for falling temperature again in intervals of 1 °C. Try to use again a cooling velocity of 1 C/minute far away from the Curie temperature and **0.2 °C/minute between 51 °C and about 47 °C** until you have passed the Curie temperature. After passing the Curie temperature you can further decrease the heating current and increase the cooling velocity again to about 1 °C/minute.

OBSERVATIONS

There are two multi-meters in the apparatus of the experiment and one of them shows us the temperature in terms of voltage which is converted into °C by using the conversion formula of **0.1V = 1°C**. The other multi-meter shows us the capacity in volts which is converted by using the conversion rate of **1mV = 1pF**. The readings are taken for increasing temperature and decreasing temperature which are provided below.

Readings for Increasing Temperature

| Temperature (°C) | Capacitance (pF) | Permittivity ϵ | Inverse Permittivity |
|------------------|------------------|-------------------------|----------------------|
| 22.2 | 26.7 | 0.856095238 | 0.010337635 |
| 23 | 26.1 | 0.836857143 | 0.010575282 |
| 24 | 29.5 | 0.945873016 | 0.009356436 |
| 25 | 30.3 | 0.97152381 | 0.009109401 |
| 26 | 31.1 | 0.997174603 | 0.008875076 |
| 27 | 32 | 1.026031746 | 0.008625464 |
| 28 | 33 | 1.058095238 | 0.008364086 |
| 29 | 34.2 | 1.096571429 | 0.00807061 |
| 30 | 35.5 | 1.138253968 | 0.007775066 |
| 31 | 37.9 | 1.215206349 | 0.007282714 |
| 32 | 40 | 1.282539683 | 0.006900371 |
| 33 | 42.2 | 1.353079365 | 0.006540636 |
| 34 | 44.6 | 1.430031746 | 0.006188674 |
| 35 | 47.2 | 1.513396825 | 0.005847772 |
| 36 | 49.9 | 1.599968254 | 0.00553136 |
| 37 | 53.5 | 1.715396825 | 0.005159156 |
| 38 | 57 | 1.827619048 | 0.004842366 |
| 39 | 60.8 | 1.949460317 | 0.004539718 |
| 40 | 63.3 | 2.029619048 | 0.004360424 |
| 41 | 67.8 | 2.173904762 | 0.004071016 |
| 42 | 73.5 | 2.356666667 | 0.003755304 |
| 43 | 80.5 | 2.581111111 | 0.003428756 |
| 44 | 91.8 | 2.943428571 | 0.003006698 |
| 45 | 110 | 3.526984127 | 0.002509226 |

| | | | |
|------|-------|-------------|-------------|
| 46 | 136.6 | 4.379873016 | 0.002020607 |
| 47 | 182 | 5.835555556 | 0.001516565 |
| 47.2 | 215 | 6.893650794 | 0.00128379 |
| 47.4 | 236 | 7.566984127 | 0.001169554 |
| 47.6 | 274 | 8.785396825 | 0.001007353 |
| 47.8 | 332 | 10.64507937 | 0.00083137 |
| 48 | 423 | 13.56285714 | 0.000652517 |
| 48.2 | 596 | 19.10984127 | 0.000463112 |
| 48.4 | 1095 | 35.10952381 | 0.000252068 |
| 48.6 | 1827 | 58.58 | 0.000151075 |
| 48.8 | 1640 | 52.58412698 | 0.000168302 |
| 49 | 1311 | 42.0352381 | 0.000210538 |
| 49.2 | 991 | 31.77492063 | 0.000278522 |
| 49.4 | 850 | 27.25396825 | 0.000324723 |
| 49.6 | 710 | 22.76507937 | 0.000388753 |
| 49.8 | 608 | 19.49460317 | 0.000453972 |
| 50 | 522 | 16.73714286 | 0.000528764 |
| 50.2 | 459 | 14.71714286 | 0.00060134 |
| 50.4 | 416 | 13.3384127 | 0.000663497 |
| 50.6 | 377 | 12.08793651 | 0.000732135 |
| 50.8 | 346 | 11.09396825 | 0.000797731 |
| 51 | 320 | 10.26031746 | 0.000862546 |
| 51.2 | 296 | 9.490793651 | 0.000932483 |
| 51.4 | 276 | 8.84952381 | 0.001000054 |
| 51.6 | 259 | 8.304444444 | 0.001065694 |
| 51.8 | 244 | 7.823492063 | 0.001131208 |
| 52 | 227 | 7.278412698 | 0.001215924 |
| 53 | 180 | 5.771428571 | 0.001533416 |
| 54 | 144.3 | 4.626761905 | 0.001912785 |
| 55 | 122.7 | 3.934190476 | 0.00224951 |
| 56 | 107.2 | 3.437206349 | 0.002574765 |
| 57 | 95.2 | 3.052444444 | 0.002899316 |
| 58 | 85.6 | 2.744634921 | 0.003224473 |
| 59 | 78 | 2.500952381 | 0.003538652 |
| 60 | 71.2 | 2.282920635 | 0.003876613 |
| 61 | 65.7 | 2.106571429 | 0.004201139 |
| 62 | 61.4 | 1.968698413 | 0.004495356 |
| 63 | 57.5 | 1.843650794 | 0.004800258 |
| 64 | 54.1 | 1.734634921 | 0.005101938 |
| 65 | 51.1 | 1.638444444 | 0.005401465 |
| 66 | 48.3 | 1.548666667 | 0.005714593 |
| 67 | 46 | 1.474920635 | 0.006000323 |
| 68 | 43.8 | 1.404380952 | 0.006301709 |

| | | | |
|----|------|-------------|-------------|
| 69 | 41.8 | 1.340253968 | 0.006603226 |
| 70 | 40.1 | 1.285746032 | 0.006883163 |
| 71 | 38.5 | 1.234444444 | 0.007169217 |
| 72 | 37 | 1.186349206 | 0.007459861 |
| 73 | 35.7 | 1.144666667 | 0.007731508 |
| 74 | 34.4 | 1.102984127 | 0.008023688 |
| 75 | 33.3 | 1.067714286 | 0.008288734 |

Readings for Decreasing Temperature


| Temperature (°C) | Capacitance (pF) | Permittivity ϵ | Inverse Permittivity |
|------------------|------------------|-------------------------|----------------------|
| 75 | 33.3 | 1.067714286 | 0.008288734 |
| 74 | 34.5 | 1.106190476 | 0.00800043 |
| 73 | 36 | 1.154285714 | 0.007667079 |
| 72 | 37 | 1.186349206 | 0.007459861 |
| 71 | 38.5 | 1.234444444 | 0.007169217 |
| 70 | 40 | 1.282539683 | 0.006900371 |
| 69 | 41.8 | 1.340253968 | 0.006603226 |
| 68 | 43.8 | 1.404380952 | 0.006301709 |
| 67 | 46 | 1.474920635 | 0.006000323 |
| 66 | 48.3 | 1.548666667 | 0.005714593 |
| 65 | 51 | 1.635238095 | 0.005412056 |
| 64 | 54.2 | 1.73784127 | 0.005092525 |
| 63 | 57.5 | 1.843650794 | 0.004800258 |
| 62 | 61.5 | 1.971904762 | 0.004488046 |
| 61 | 66.2 | 2.122603175 | 0.004169409 |
| 60 | 71.5 | 2.292539683 | 0.003860348 |
| 59 | 78.3 | 2.510571429 | 0.003525094 |
| 58 | 85.6 | 2.744634921 | 0.003224473 |
| 57 | 95.2 | 3.052444444 | 0.002899316 |
| 56 | 107.2 | 3.437206349 | 0.002574765 |
| 55 | 122.8 | 3.937396825 | 0.002247678 |
| 54 | 143.8 | 4.610730159 | 0.001919436 |
| 53 | 174.4 | 5.591873016 | 0.001582654 |
| 52 | 230 | 7.374603175 | 0.001200065 |
| 51.8 | 242 | 7.759365079 | 0.001140557 |
| 51.6 | 260 | 8.336507937 | 0.001061596 |
| 51.4 | 274 | 8.785396825 | 0.001007353 |
| 51.2 | 296 | 9.490793651 | 0.000932483 |
| 51 | 318 | 10.19619048 | 0.000867971 |
| 50.8 | 346 | 11.09396825 | 0.000797731 |
| 50.6 | 377 | 12.08793651 | 0.000732135 |
| 50.4 | 418 | 13.40253968 | 0.000660323 |
| 50.2 | 470 | 15.06984127 | 0.000587266 |
| 50 | 537 | 17.21809524 | 0.000513994 |

| | | | |
|------|-------|-------------|-------------|
| 49.8 | 632 | 20.26412698 | 0.000436732 |
| 49.6 | 760 | 24.36825397 | 0.000363177 |
| 49.4 | 970 | 31.1015873 | 0.000284551 |
| 49.2 | 1332 | 42.70857143 | 0.000207218 |
| 49 | 2590 | 83.04444444 | 0.000106569 |
| 48.8 | 3520 | 112.8634921 | 7.84133E-05 |
| 48.6 | 4112 | 131.8450794 | 6.71242E-05 |
| 48.4 | 3400 | 109.015873 | 8.11808E-05 |
| 48.2 | 2860 | 91.7015873 | 9.65087E-05 |
| 48 | 2430 | 77.91428571 | 0.000113586 |
| 47.8 | 2100 | 67.33333333 | 0.000131436 |
| 47.6 | 1849 | 59.28539683 | 0.000149278 |
| 47.4 | 1674 | 53.67428571 | 0.000164883 |
| 47.2 | 1559 | 49.98698413 | 0.000177046 |
| 47 | 1452 | 46.55619048 | 0.000190093 |
| 46 | 1119 | 35.87904762 | 0.000246662 |
| 45 | 915 | 29.33809524 | 0.000301656 |
| 44 | 757 | 24.27206349 | 0.000364617 |
| 43 | 636 | 20.39238095 | 0.000433986 |
| 42 | 553 | 17.73111111 | 0.000499123 |
| 41 | 480 | 15.39047619 | 0.000575031 |
| 40 | 424 | 13.59492063 | 0.000650978 |
| 39 | 376 | 12.05587302 | 0.000734082 |
| 38 | 336 | 10.77333333 | 0.000821473 |
| 37 | 301 | 9.651111111 | 0.000916993 |
| 36 | 272 | 8.721269841 | 0.00101476 |
| 35 | 247 | 7.91968254 | 0.001117469 |
| 34 | 225 | 7.214285714 | 0.001226733 |
| 33 | 205 | 6.573015873 | 0.001346414 |
| 32 | 181.8 | 5.829142857 | 0.001518234 |
| 31 | 166.4 | 5.335365079 | 0.001658743 |
| 30 | 153.5 | 4.921746032 | 0.001798142 |
| 29 | 142.4 | 4.56584127 | 0.001938307 |
| 28 | 130.2 | 4.174666667 | 0.00211993 |

GRAPHS & DISCUSSIONS


PERMITTIVITY

The graphical representation shows a change in permittivity concerning increasing Temperature. Here from the graph, it is observed that at **48.6°C** we got a highest permittivity and the approximate value of this is **58.58 pF/mm**. Similarly, while decreasing the temperature of the sample to **48.6°C** we got a peak permittivity of **131.8451 pF/mm**. The graphs for the cycles are shown below.



Graph 3: Permittivity vs Temperature under Heating process

From Graph 3, we can observe that the permittivity of the sample remains almost constant with very low increase in values at lower temperatures from 22.2°C till 45°C. But we see there is a Sudden peak rise in the permittivity level from 45°C till temperature 48.6°C where the highest permittivity (58.58 pF/mm) is seen while Heating.




Graph 4: Permittivity vs Temperature under Cooling process

From Graph 4, we can observe the similar process while cooling from 75°C to 53°C as in Heating process. After reaching the temperatures less than 53°C, the permittivity of the sample gained rapid increase to the peak of 131.8451 pF/mm (2.5 times compared to Heating) at 48.6°C. Later, it attained gradual decrease.


When compared with Theoretical values by Curie-Weiss law, at 49°C the material converts its properties from Ferroelectric to Paraelectric.

INVERSE OF RELATIVE PERMITTIVITY



Graph 5: Inverse relative permittivity vs temperature under Heating process

From Graph 5, on heating, the value for inverse relative permittivity decreases till curie temperature and it starts increasing gradually after curie temperature.



Graph 6: Inverse relative permittivity vs temperature under cooling process

From Graph 6, while cooling, we can see the Relative permittivity values at lower temperatures (less than Curie temperature) are less when compared with Heating.

CONCLUSION

According to Landau theory and Curie-Weiss law, a material acts as a ferroelectric material when the temperature is less than the Curie temperature and as a para-electric material when the temperature is greater than the Curie temperature. In the inverse relative permittivity graphs for both heating and cooling, we observe that the process of TGS crystal changing from ferroelectric to para-electric substance takes place continuously without breakage and with no loss of energy. Therefore, we can conclude that the transition which we see here is a **Second-order transition**. By comparing both the Theoretical and Practical graphs we can see that the slope of the curve in inverse relative permittivity almost reaches zero at Curie temperature.

In this experiment, we obtained **Curie Temperature (T_c)** under Heating and Cooling processes at **48.6°C** and we know the theoretical value of T_c for TGS crystal is 49°C.